

Multifunctional rotary actuator for 2 and 3 way control ball valves.

- Torque 20 Nm
- Nominal voltage AC/DC 24 V
- Control: Modulating DC 0 ... 10 V or variable
- Position feedback DC 2 ... 10 V or variable



Technical data				
Electrical data				
Nominal voltage	AC 24 V, 50/60 Hz / DC 24 V			
Power supply range	AC 19.2 28.8 V / DC 21.6 28.8 V			
Power consumption In operation	4 W at nominal torque			
At rest	1.25 W			
For wire sizing	6 VA			
Connection	Cable 1 m, 4 x 0.75 mm <sup>2</sup>			
Functional data	Factory settings	Variable	Settings	
Torque (nominal torque)	Min. 20 Nm at nominal voltage			
Control Control signal Y	DC 0 10 V, input impedance 100 k $\Omega$	Open-close, 3-point (AC only)		
Working range	DC 2 10 V	Start point DC 0.5 30 V		
		End point DC 2.5 32 V		
Position feedback (measuring voltage U)	DC 2 10 V, max. 0.5 mA	Start point DC 0.5 8 V		
		End point DC 2.5 10 V		
Jni-rotation	±5% absolutely			
Running time	90 s / 90°∢	90 150 s		
Automatic adjustment of running time,	Manual triggering of this adaption by	Automatic adaption whenever		
operating range and measuring signal U	pressing the button «Adaption» or with	the supply voltage is switched		
o match the mechanical angle of rotation	the PC-Tool	on, or manual triggering		
Angle of rotation limiting	MAX (maximum position) = 100%	MAX = (MIN + 30°<) 100%		
	MIN (minimum position) = 0%	(		
	ZS (intermediate position, AC only) = 50%	ZS = MIN MAX		
Sound power level	Max. 35 dB (A)	With a running $90 \text{ s} = 45 \text{ dB (A)}$ time of $150 \text{ s} = 35 \text{ dB (A)}$		
Position indication	Mechanical, plug-on			
Safety				
Protection class	III Safety extra-low voltage			
Degree of protection	IP54 in all mounting positions			
EMC	CE according to 89/336/EEC			
Mode of operation	Type 1 (to EN 60730-1)			
Rated impulse voltage	0.8 kV (to EN 60730-1)			
Control pollution degree	3 (in acc. with EN 60730-1)			
Ambient temperature range	+0 +50°C			
Temperature of medium	+5 +100°C in control ball valve			
•	–10°C with stem heating upon request			
Non-operating temperature	−40 +80°C			
Ambient humidity range	95% r.H., non-condensating (to EN 60730-1	)		
Maintenance	Maintenance-free			
Dimensions/weight				
Dimensions	See «Dimensions» on page 5			
Weight	Approx. 500 g			



#### Safety notes



- The damper actuator is not allowed to be used outside the specified field of application, especially in aircraft or in any other airborne means of transport.
- It may only be installed by suitably trained personnel.
   All applicable legal or institutional installation regulations must be complied with.
- The switch for changing the direction of rotation may only be operated by authorized personnel. The direction of rotation must not be reversed in a frost protection circuit.
- The device may only be opened at the manufacturer's site. It does not contain any parts that can be replaced or repaired by the user.
- · The cable is not allowed to be removed from the unit.
- The device contains electrical and electronic components and is not allowed to be disposed
  of as household refuse. All locally valid regulations and requirements must be observed.

#### **Product features**

Mode of operation

The actuator is controlled with a standard modulating signal of DC  $0\dots 10\ V$  and travels to the position defined by the control signal. Measuring voltage U serves for the electrical display of the actuator position  $0\dots 100\%$  and as slave control signal for other actuators.

Parameterisable actuators

The factory settings cover the most common applications. Input and output signals and other parameters can be altered with the MFT-H parameterising device or the BELIMO Service Tool, MFT-P.

Simple direct mounting

Straightforward direct mounting on the ball valve with only one screw. The mounting position in relation to the ball valve can be selected in 90°< steps.

Manual override

Manual operation with pushbutton possible - temporary, permanently. The gear is disengaged and the actuator decoupled for as long as the button is pressed / latched.

Adjustable angle of rotation

Adjustable angle of rotation with mechanical end stops.

High functional reliability

The actuator is overload-proof, requires no limit switches and automatically stops when the end stop is reached.

Home position

When the supply voltage is switched on for the first time, i.e. at commissioning or after pressing the "gear disengagement" switch, the actuator travels to the home position. Factory setting: Direction of rotation Y2 (counter-clockwise rotation)

Rotary actuator	Rotary valve	
<b>√</b> Y2	A – AB = 0%	
Y1.	A – AB = 100%	

The actuator then moves into the position defined by the control signal.

# **Accessories**

# **Electrical accessories**

Description	Data sheet T2 - SA	
Auxiliary switch SA		
Feedback potentiometer PA	T2 - PA	
Parameterizing device MFT-H T2 - MF		
PC-Tool MFT-P	T2 - MFT-P	
Positioner SG24	T2 - SG24	
Digital position indicator ZAD24	T2 - 7AD24	




# **Electrical installation**

#### Wiring diagram

# Note


- Connect via safety isolation transformer.
- Parallel connection of other actuators possible.
- Direction of rotation switch is covered.

Factory setting: Direction of rotation Y2




# Functions with basic values

# Override control with AC 24 V with relay contacts




# Override control with AC 24 V with rotary control switch




	1
Pos	Functions
1	0% ∢
2	ZS 50% ⊲ (intermediate position)
3	100% ⊲
4	Control mode


#### Remote control 0 ... 100 %




#### Minimum limit



# Master/Slave control (position-dependent)



# Control with 4 ... 20 mA via external resistance




The 500  $\Omega$  resistor converts the 4 ... 20 mA current signal to a voltage signal DC 2 ... 10 V




# **Functions with basic values**

# Position indication



#### **Functional check**




#### Procedure

- Apply AC 24 V to connection 1 and 2
- · Disconnect connection 3:
  - For direction of rotation Y1:
  - Actuator turns in the direction of
  - For direction of rotation Y2:
     Actuator turns in the direction of
- Short circuit connections 2 and 3:
  - Actuator runs in the opposite direction

# Functions for actuators with specific parameters


# Override control and limiting with AC 24 V with relay contacts




Functions	а	b	е
CLOSE 1)	1		
OPEN		1	
Control mode in accordance with Y		<u></u>	1


1) Caution! This function is only guaranteed if the start point of the operating range is defined as min. 0.6 V.

#### 3-point control






#### Open/close control (1 wire)






# **Dimensions [mm]**

#### **Dimensional diagrams**





# Operating controls and indicators



#### 1) Direction of rotation switch

Switching over: Direction of rotation changes

#### 2 Pushbutton and green LED display

Off: No voltage supply or malfunction

Green on: Operation

Press button: Switches on angle of rotation adaption followed by standard operation

## 3 Pushbutton and yellow LED display

Off: Standard operation

Yellow on: Adaption or synchronising process active

Press button: No function

# 4 Gear disengagement switch

Press button: Gear disengaged, motor stops, manual operation possible

Release button: Gear engaged, synchronisation starts, followed by standard operation

# 5 Service plug

For connecting parameterising and service tools

**Further documentations** 

- Complete overview of actuators for water solutions
- Data sheets for butterfly valves
- · Installation instructions for actuators and/or ball valves
- Notes for project planning (hydraulic characteristic curves and circuits, installation regulations, commissioning, maintenance etc.)

Data sheet T2-SR24A-MF • en • v1.3 • 08.2006 • Subject to modifications



