

Rotary actuator for 2 and 3-way (control) ball valves

- Torque 5 Nm
- · Nominal voltage AC 100 ... 240 V
- · Control: Open/close or 3-point
- · Auxiliary switch



Technical data			
Electrical data	Nominal voltage		AC 100 240 V, 50/60 Hz
	Power supply range		AC 85 265 V
	Power consumption	In operation	1.5 W at nominal torque
		At rest	0.4 W
		For wire sizing	4 VA
	Auxiliary switch		1 x SPDT, 1 mA 3 (0.5) A, AC 250 V II □ (0 100% adjustable)
	Connection	Motor	Cable 1 m, 3 x 0.75 mm ²
		Auxiliary switch	Cable 1 m, 3 x 0.75 mm ²
	Parallel connection	•	Possible, note performance data
Functional data	Torque (nominal torque)		Min. 5 Nm at nominal voltage
	Manual override		Gearing latch disengaged with pushbutton
			(temporary-permanent)
	Running time		90 s / 90° <
	Noise level		Max. 35 dB (A) (without the valve)
	Position indication		Mechanical, add-on
Safety	Protection class Degree of protection		II Totally insulated □
			IP54 in any mounting position
	EMC		CE according to 89/336/EEC
	Mode of operation		Type 1 (to EN 60730-1)
	Rated impulse voltage		4 kV (to EN 60730-1)
	Control pollution degree		3 (to EN 60730-1)
	Ambient temperature range		0 +50°C
	Media temperature		+5 +110°C in (control) ball valve
	Non-operating temperature Ambient humidity range Maintenance		-10°C with stem heating upon request
			−40 +80°C
			95% r.H., non-condensating (to EN 60730-1)
			Maintenance-free
Dimensions / Weight	Dimensions / Weight Dimensions Weight		See «Dimensions» on page 2
			Approx. 600 g

Safety notes



- The rotary actuator has been designed for use in stationary heating, ventilation and air conditioning systems and is not allowed to be used outside the specified field of application, especially in aircraft or in any other airborne means of transport.
- · Caution power supply voltage!
- It may only be installed by suitably trained personnel.
 All applicable legal or institutional installation regulations must be complied with.
- The switch for changing the direction of rotation may only be operated by authorized personnel. The direction of rotation must not be reversed in a frost protection circuit.
- The device may only be opened at the manufacturer's site. It does not contain any parts that
 can be replaced or repaired by the user.
- · The cable must not be removed from the device.
- The device contains electrical and electronic components and is not allowed to be disposed
 of as household refuse. All locally valid regulations and requirements must be observed.

www.belimo.com 1



Product features

Simple direct mounting Straightforward direct mounting on the ball valve with only one screw. The assembly tool is

integrated in the plug-on position indicator. The mounting position in relation to the ball valve can

Rotary actuator Rotary valve

Adjustable angle of rotation Adjustable angle of rotation with mechanical end stops.

High functional reliability The actuator is overload-proof, requires no limit switches and automatically stops when the

end stop is reached.

Open-close control

Flexible signalization Flexible signalization with adjustable auxiliary switch (0 ... 100%).

Accessories

Description Data sheet Auxiliary switch S..A.. T2 - S..A.. **Electrical accessories** Feedback potentiometer P..A.. T2 - P..A..

Electrical installation

Wiring diagram

Notes

· Caution power supply voltage!


- · Parallel connection of other actuators possible. Note performance data.
- · Direction of rotation switch is covered. Factory setting: Direction of rotation Y2



Auxiliary switch












3-point control



Dimensions [mm]

Dimensional diagrams





Further documentations

- Complete overview of actuators for water solutions
- Data sheets for ball valves
- Installation instructions for actuators and/or ball valves
- Notes for project planning (hydraulic characteristic curves and circuits, installation regulations, commissioning, maintenance etc.)



