

Multifunctional Robustline damper actuator for operating air dampers in industrial plants and in the technical building installations

- For air dampers up to approx. 1.6 m²
- Torque 8 Nm
- Nominal voltage AC/DC 24 V
- Control: modulating DC 0 ... 10 V or variable
- Position feedback DC 2 ... 10 V or variable

Optimum protection against

- · Corrosion and chemical influences
- UV radiation
- Damp and condensation



| Electrical data | | | |
|---|---|--|----------|
| Nominal voltage | AC 24 V, 50/60 Hz / DC 24 V | | |
| Nominal voltage range | AC 19.2 28.8 V / DC 21.6 28.8 V | | |
| Power consumption Operation | 3.5 W @ nominal torque | | |
| At rest | 1.25 W | | |
| Wire sizing | 5.5 VA | | |
| Connection | Halogen-free cable 1 m, 4 x 0.75 mm ² | | |
| Functional data | Factory settings | Variable | Settings |
| Torque (nominal torque) | Min. 8 Nm @ nominal voltage | 25%, 50%, 75% reduced | |
| Control Control signal Y | DC 0 10 V, input impedance 100 k Ω | Open-close / 3-point (only AC), | |
| | | modulating (DC 0 32 V) | |
| Operating range | DC 2 10 V | Starting point DC 0.5 30 V | |
| | | End point DC 2.5 32 V | |
| Position feedback (measuring voltage U) | DC 2 10 V, max. 0.5 mA | Starting point DC 0.5 8 V | |
| D. W | .50/ | End point DC 2.5 10 V | |
| Position accuracy | ±5% | | |
| Direction of rotation | Reversible with switch 0 / 1 | 5 1 | |
| Direction of motion at Y = 0 V | At switch position 0 🖍 resp. 1 🤼 | Electronically reversible | |
| Manual override | Gearing latch disengaged with pushbutton, can be locked | | |
| Angle of rotation | Max. 95° | | |
| Running time | 150 s / 90°⊄ | 43 173 s | |
| Automatic adjustment of running time, operating | Manual triggering of the adaption by pressing | | |
| range and measuring signal U to match the | the «Adaption» button or with the PC-Tool | whenever the supply voltage is | |
| mechanical angle of rotation | | switched on | |
| Override control | MAX (maximum position) = 100% | MAX = (MIN + 30°<) 100% | |
| | MIN (minimum position) = 0% | MIN = 0% (MAX − 30°<) | |
| Cound newer level | ZS (intermediate position, only AC) = 50% Max. 35 dB (A) | ZS = MIN MAX With a running 43 s = 45 dB (A) | |
| Sound power level | Max. 55 db (A) | time of $43 \text{ s} = 45 \text{ dB (A)}$ | |
| Position indication | Mechanical, pluggable | (A) | |
| | moonailloai, pluggabie | | |
| Safety | III Cofeby outre less voltes :- | | |
| Protection class | III Safety extra-low voltage | | |
| Degree of protection | IP66 + IP67 | | |
| EMC Made of energina | CE according to 2004/108/EC | | |
| Mode of operation | Type 1 (EN 60730-1) | | |
| Rated impulse voltage | 0.8 kV (EN 60730-1) | | |
| Control pollution degree | 4 (EN 60730-1) | | |
| Ambient temperature | −30 +50°C | | |
| Non-operating temperature | -40 +80°C | | |
| Ambient humidity | 100% r.H. | | |
| Maintenance | Maintenance-free | | |
| Dimensions / Weight | | | |
| Dimensions | See «Dimensions» on page 6 | | |
| Weight | Approx. 1.3 kg | | |



Safety notes



- The actuator is not allowed to be used outside the specified field of application, especially in aircraft or in any other airborne means of transport.
- It may only be installed by suitably trained personnel. Any legal regulations or regulations issued by authorities must be observed during assembly.
- The cover of the protective housing may be opened for adjustment and servicing. When it is closed afterwards, the housing must seal tight (see installation instructions).
- The device on the inside may only be opened up in the factory. It does not contain any parts that can be replaced or repaired by the user.
- · The cable must not be removed from the device.
- When calculating the required torque, the specifications supplied by the damper manufacturers (cross section, design, installation site), and the air flow conditions must be observed.
- The device contains electrical and electronic components and is not allowed to be disposed
 of as household refuse. All locally valid regulations and requirements must be observed.
- The information on chemical resistance refers to laboratory tests with raw materials and finished products and to trials in the field in the areas of application indicated.
- The materials used may be subjected to external influences (temperature, pressure, constructional fixture, effect of chemical substances etc.), that cannot be simulated in laboratory test or field trials.
- The information regarding areas of application and resistance can therefore only serve as a guideline. In case of doubt, we recommend that you definitely carry out a test. This information does not imply any legal entitlement. Belimo will not be held liable and will provide no warranty. The chemical or mechanical resistance of the materials used is not alone sufficient for judging the suitability of a product. Regulations pertaining to combustible liquids such as solvents etc. must be taken into account with special reference to explosion protection.

Product features

Fields of application

The actuator is particularly suited for use in difficult conditions, e.g. in the field of:

- Wood drying
- Animal breeding
- Food processing
- Agricultural
- Swimming baths / Bathrooms
- Rooftop units
- General outdoor applications
- Changing atmosphere

Resistances

| Test | Test standard | Testing body | |
|-----------------------------------|----------------|-------------------------------|--|
| Noxious gas tests | EN 60068-2-60 | Fraunhofer Institute ICT / DE | |
| Salt fog spray test | EN 60068-2-52 | Fraunhofer Institute ICT / DE | |
| Ammoniac test | DIN 50916-2 | Fraunhofer Institute ICT / DE | |
| Climatic test | IEC 60068-2-30 | Trikon Solutions AG / CH | |
| Disinfectants (animals) | | Trikon Solutions AG / CH | |
| UV test | EN 60068-2-5 | Ovinal / Zva CII | |
| (Solar radiation at ground level) | EN 60068-2-63 | Quinel / Zug CH | |

Used materials

| Actuator parts | Material | |
|-----------------------------|--------------------|--|
| Actuator housing | Polypropylene (PP) | |
| Cable glands / hollow shaft | Polyamide (PA) | |
| Connection cable | FRNC | |
| Clamp / screws in general | Steel 1.4404 | |
| Seals | EPDM | |
| Form-fit insert | Anodised aluminium | |

Multifunctional Robustline damper actuator, AC/DC 24 V, 8 Nm



| Product features | (continued) | | |
|------------------------------|---|--|--|
| Mode of operation | The actuator is controlled with a standard modulating signal of DC 0 10 V and travels to the position defined by the control signal. The measuring voltage U serves for the electrical display of the damper position 0 100% and as slave control signal for other actuators. | | |
| Parameterisable actuators | The factory settings cover the most common applications. | | |
| Simple direct mounting | Simple direct mounting on the damper spindle with a universal spindle clamp, supplied with an anti-rotation strap to prevent the actuator from rotating. | | |
| Manual override | Manual override with pushbutton possible (the gear is disengaged for as long as the button is pressed or remains locked). | | |
| Adjustable angle of rotation | Adjustable angle of rotation with mechanical end stops. Standard setting 0 90° ∴ The housing cover must be removed to set the angle of rotation. | | |
| High functional reliability | The actuator is overload-proof, requires no limit switches and automatically stops when the end stop is reached. | | |
| Home position | When the supply voltage is switched on for the first time, i.e. at commissioning or after pressing the «gear disengagement» switch, the actuator moves to the home position. | | |
| | Pos. Direction of rotation switch Home position | | |
| | | | |

| Pos. Direction of rotation switch | Home position |
|-----------------------------------|---------------|
| Y = 0 🚩 | ccw Left stop |
| Y = 0 ~ | Cw Right stop |

The actuator then moves into the position defined by the control signal.

| Accessories | | |
|------------------------|------------------------------------|------------|
| | Description | Data sheet |
| Electrical accessories | Auxiliary switch SA | T2 - SA |
| | Feedback potentiometer PA | T2 - PA |
| | Manual parameterising device MFT-H | T2 - MFT-H |
| | PC-Tool MFT-P | T2 - MFT-P |
| | Range controller SBG24 | T2 - SBG24 |
| | Positioner SG24 | T2 - SG24 |
| | Digital position indication ZAD24 | T2 - ZAD24 |
| Mechanical accessories | Various form-fit inserts | T2 - Z-NM |


Electrical installation

Wiring diagram

Note

· Connect via safety isolation transformer.

• Other actuators can be connected in parallel. Note the performance data.



Cable colours:


1 = black

2 = red 3 = white 5 = orange




Functions with basic values


Override control with AC 24 V with relay contacts




Override control with AC 24 V with rotary control switch




Remote control 0 ... 100%




Minimum limit



Master/Slave control (position-dependent)




Control with 4 ... 20 mA via external resistance




The 500 Ω resistor converts the 4 ... 20 mA current signal to a voltage signal DC 2 ... 10 V

Position indication



Functional check




Procedure

- Apply AC 24 V to connection 1 and 2
- Disconnect connection 3:
- For direction of rotation 0:
- Actuator turns in the direction of *
- For direction of rotation 1:
 Actuator turns in the direction of
- Short circuit connections 2 and 3:
- Actuator runs in the opposite direction




Functions for actuators with specific parameters

Override control and limiting with AC 24 V with relay contacts





Override control and limiting with AC 24 V with rotary switch




¹⁾ Caution! This function is only guaranteed if the start point of the operating range is defined as min. 0.6 V.

3-point control







Operating controls and indicators



- Direction of rotation switch
 - Switching over:: Direction of rotation changes
- 2 Push-button and green LED display

Off: No voltage supply or fault

On: Operation

Press button: Switches on angle of rotation adaptation followed by standard operation

3 Pushbutton and yellow LED display

Off: Standard operation

On: Adaptation or synchronising process active

Press button: No function

4 Gear disengagement switch

Press button: Gear disengaged, motor stops, manual override possible

Release button: Gear engaged, synchronisation starts, followed by standard operation

5 Service plug

For connecting parameterising and service tools


Check connection power supply


Off (3) On or flashing fl



Dimensions [mm]


Dimensional drawings








| Damper spindle | Length | <u>OĪ</u> | ■Ⅲ | <u>♦</u> <u>1</u> |
|----------------|--------|-----------|-----|-------------------|
| | 2058 | 820 | 814 | 1020 |

























AC 24 V / DC 24 V



NM24P-SR.. SM24P-SR.. NM24P-MF.. SM24P-MF..



